



## ME777-CRK POL FILLER VALVE COUPLER REPAIR KIT

### !!!WARNING!!!

READ AND UNDERSTAND ALL INSTRUCTIONS INCLUDED WITH THIS REPAIR KIT  
RELIEVE ALL PRESSURE FROM SYSTEM BEFORE REMOVING VALVE FOR SERVICE

**NOTE:** Numbers in brackets [ ] refer to the number in the valve component list.

### !WARNING!

Relieve all pressure from system before removing valve for service, and before any disassembly or repair.

Read and understand all instructions included with the repair kit, prior to starting any repairs.

### !GENERAL WARNING!

Marshall Excelsior products are mechanical devices that are subject to wear, contaminants, corrosion, and aging of components made of materials such as rubber and metal. Over time these devices will eventually become inoperative. The safe service life of these products will reflect the environment and conditions of use that they are subjected to. Regular inspection and maintenance is essential. Marshall Excelsior products have a long record of quality and service, so LP-Gas dealers may forget hazards that can arise from using aging devices that have outlived their safe service life.



**WARNING:** These products contain a chemical known to the state of California to cause cancer and birth defects or reproductive harm

#### A. Disassembly of ME777 Filler Valve

1. Fully open valve.
2. Remove Body Set Screw [2] from Body [1] and retain.
3. Unthread POL Tailpiece [4], remove Bushing [7] and retain.
4. Remove Bearing [5] and POL Nut [6] and discard.
5. Remove Body O-ring [3] and discard.

#### B. Reassembly

1. Apply Lubriplate or equivalent grease to Body O-ring [3]. Install Body O-ring into Body [1].
2. Install Bearing [5] and POL Nut [6] onto POL Tailpiece [4].
3. Install POL Tailpiece [4] into Body [1] and torque to 50 ft-lbs.
4. Install Body Set Screw [2] into Body [1] and torque to 50 in-lbs.

After reassembly, connect the Filler Valve inlet to a pressure source of at least 150 psi. Check for leaks at all assembly joints using a suitable leak detector solution such as "Marshall Excelsior" leak detector.

### !CAUTION!

Torque specifications on the POL Tailpiece (50 ft-lbs) and Body Set Screw (50 in-lbs) must be met to insure a proper and reliable seal.

If any joint or seal continues to leak after reassembly, do not continue to use the valve.

### Marshall Excelsior Company

1506 George Brown Drive Marshall, MI 49068  
Phone (269) 789-6700 Fax (269) 781-8340  
www.marshallexcelsior.com

The contents of this publication are for informational purposes only. While every effort has been made to ensure accuracy, these contents are not to be construed as warranties or guarantees, expressed or implied, regarding the products or services described herein or for their use or applicability. Marshall Excelsior Co. reserves the right to modify or improve the designs or specifications of such products at any time without notice. The MEC™ logo is the trademark of Marshall Excelsior Co.

## ME777-CRK

| Item Number | Description    | Qty. | Included in Repair kit |
|-------------|----------------|------|------------------------|
| 1           | Body           | 1    | No                     |
| 2           | Body Set Screw | 1    | No                     |
| 3           | Body O-ring    | 1    | Yes                    |
| 4           | POL Tailpiece  | 1    | No                     |
| 5           | Bearing        | 1    | Yes                    |
| 6           | POL Nut        | 1    | Yes                    |
| 7           | Bushing        | 1    | No                     |

