



MEGR-167CH/751 GAS REGULATOR

Instruction Manual- Look Inside For:

Description
Installation
Operation
Maintenance
Parts Ordering
Parts List



Marshall Excelsior Company

Marshall, MI 49068
269-789-6700
FAX 269-781-8340

www.marshallexcelsior.com



WARNING: These products contain a chemical known to the state of California to cause cancer and birth defects or reproductive harm

The contents of this publication are for informational purposes only. While every effort has been made to ensure accuracy, these contents are not to be construed as warranties or guarantees, expressed or implied, regarding the products or services described herein or for their use or applicability. Marshall Excelsior Co. reserves the right to modify or improve the designs or specifications of such products at any time without notice. The MEC™ logo is the trademark of Marshall Excelsior Co.



MEGR-167CH/751 GAS REGULATOR INSTRUCTIONS

These regulators are designed for air and gas service. Maximum pressures are described on the individual labels. Operating temperatures are 0° to 160°F.

INSTALLATION:

Install the regulator as close to the instrument or tool it is to service. The words "IN" and "OUT" are cast in the body to indicate the direction of flow. (NOTE: If a lubricator is to be used in the system, install it downstream of the regulator.)

OPERATION:

MEGR-167CH/751: Before turning on the supply air, screw out the adjusting screw until there is no compression on the regulating spring. Turn on the air supply and turn the adjusting screw until the desired secondary pressure is reached.

WARNING: The MEGR-167CH/751 is supplied with a 1/4"-18 NPT tapped vent port that allows for installation of plumbing to capture exhaust gas. Under no circumstances should this exhaust port be plugged. The plugging of the vent port will cause damage to the internal components of the regulator and prevent the regulator from functioning properly.

MAINTENANCE:

Periodic cleaning of the filter is recommended on MEGR-167CH/751 regulators.

- A. To remove condensate, slowly open drain valve and bleed accumulated liquid.
- B. To clean filter element:
 - 1) Shut off air supply.
 - 2) Drain condensate.
 - 3) Remove large bolt from bottom of unit
 - 4) Remove bowl, filter and gasket.
 - 5) Clean all parts thoroughly and reassemble in reverse order.
- C. To install replacement parts:
 - 1) Order repair kit for MEGR-167CH/751
 - 2) Shut off air supply. Screw out adjusting screw.
 - 3) Remove 4 screws and bottom hex head screw and remove all parts.
 - 4) Replace parts that show excessive wear with items in kit.
 - 5) Clean all parts and replace in reverse order.
 - 6) The pintle spring screw should be installed finger tight with a screw driver. Bottom hex head screw should be torqued to 22-25 ft./lbs.

Direct any specific questions to the nearest MEC sales engineer or to the factory.