

ME807CRK AND ME807SCRK LOW EMISSION SHUTOFF VALVE COUPLING REPAIR KIT

!!!WARNING!!!

READ AND UNDERSTAND ALL INSTRUCTIONS INCLUDED WITH THIS REPAIR KIT RELIEVE ALL PRESSURE FROM SYSTEM BEFORE REMOVING VALVE FOR SERVICE

NOTE: Numbers in brackets [] refer to the number in the valve component list.



WARNING: These products contain a chemical known to the state of California to cause cancer and birth defects or reproductive harm

A. Disassembly

- 1. EVACUATE ALL PRESSURE FROM SYSTEM BEFORE ANY DISASSEMBLY OR REPAIR.
- 2. With valve in open position, remove (2) set screws [2] from Valve Body [1] and discard.
- 3. Remove Adapter [3] and Acme Gasket [4] from Valve Body [1] and discard.
- 4. Remove Adapter O-Ring [5] from Valve Body [1] and discard.
- 5. Inspect Valve Body [1] and clean if necessary, be sure interior is free of dirt, residue, and foreign particles.

B. Reassembly

!WARNING!

Failure to follow these instructions could cause risk of serious injury or death.

- 1. With valve in open position, apply lubriplate or suitable lubricant to Valve Body [1] and install Adapter O-Ring [5] into Valve Body [1].
- 2. Apply Loctite #242 (blue) or equivalent thread locker to threads of Adapter [3] and install into Valve Body [1]. Torque Adapter [3] to 160±10 ft. lbs.

- 3. Install (2) Set Screws [2] into Valve Body [1] and torque to 80 in lbs.
- 4. Install Acme Gasket [4] into Adapter [3].
- 5. Connect the valve assembly outlet to a pressure source of at least 150 PSI. Check for leaks at all joints using a suitable leak detector solution such as "Marshall Excelsior" leak detector. CAUTION: DO NOT USE THE VALVE IF ANY JOINT CONTINUES TO LEAK UNDER PRESSURE.

C. Part Number and Component List

ME807-16-01 Valve Body
ME807-16-07 Set Screw, Qty: 2

3. Adapter

ME807-16-02 BrassME807S-16-02 Steel

4. MEW6 Acme Gasket

5. ME806HN-16-07 Adapter O-Ring



Marshall Excelsior Company

1506 George Brown Drive Marshall, MI 49068 Phone (269) 789-6700 Fax (269) 781-8340 www.marshallexcelsior.com

The contents of this publication are for informational purposes only. While every effort has been made to ensure accuracy, these contents are not to be construed as warranties or guarantees, expressed or implied, regarding the products or services described herein or for their use or applicability. Marshall Excelsior Co. reserves the right to modify or improve the designs or specifications of such products at any time without notice. The MECTM logo is the trademark of Marshall Excelsior Co.

Form #971 Rev B 11/9/17