



**Application:**

Designed for use in large stationary LPG containers as a primary pressure relief valve. These pressure relief valves have been specifically designed to provide optimum performance when installed in an NPT half or full coupling, making them perfect for most large stationary tank installations.

**Features:**

- Durable brass body with NPT connection (see size below)
- Plated steel spring, nut and stem for corrosion resistance
- Furnished with cover cap for protection against contamination
- Cover cap can also be ordered separately – see Accessories below
- Available with 250 and 275 PSI set pressures

Part No.	STD (psig)	Container Connection	Installation Hex	Flow Capacity	Service	
				UL @ 120% Set Pressure	LPG	NH <sub>3</sub>
MEVS-UVE433AM/250	250	3/4" NPT	1-11/16"	1930	Yes	No
MEVS-UVE433AC/275	275	3/4" NPT	1-11/16"	--	Yes	No
MEVS-UVE443AM/250	250	1" NPT	1-7/8"	2755	Yes	No
MEVS-UVE443AC/275	275	1" NPT	1-7/8"	--	Yes	No
MEVS-UVE453AM/250	250	1-1/4" NPT	2-7/16"	4640	Yes	No
MEVS-UVE453AC/275	275	1-1/4" NPT	2-7/16"	--	Yes	No

\* Flow Rates are shown as bare relief valves.

\*\* Size relief capacity per NFPA 58 2011, table 5.7.2.6

Accessories	
Part No.	Description
MEPS-433-45A	Cover Cap for 3/4" Relief Valve
MEPS-443-45A	Cover Cap for 1" Relief Valve
MEPS-453-45A	Cover Cap for 1-1/4" Relief Valve

**Marshall Excelsior Company**  
1506 George Brown Drive Marshall, MI 49068  
Phone (269) 789-6700 Fax (269) 781-8340  
www.marshallexcelsior.com

The contents of this publication are for informational purposes only. While every effort has been made to ensure accuracy, these contents are not to be construed as warranties or guarantees, expressed or implied, regarding the products or services described herein or for their use or applicability. Marshall Excelsior Co. reserves the right to modify or improve the designs or specifications of such products at any time without notice. The MEC™ logo is the trademark of Marshall Excelsior Co.

## MEVS-UVE433, MEVS-UVE443, MEVS-UVE453 SEMI-INTERNAL PRESSURE RELIEF VALVES

---

### Operation of Pressure Relief Valves

Pressure relief valves are set and sealed by the manufacturer to function at a specific “start-to-discharge” pressure in accordance with UL 132. This set pressure is marked on the relief valve and depends on the design requirement of the container to be protected by the relief valve. If the container pressure reaches the start-to-discharge pressure, the relief valve will open a slight amount as the seat disc begins to move slightly away from the seat. If the pressure continues to rise despite the initial discharge through the relief valve, the seat disc will move to a full open position with a sudden “pop”. This popping sound is from which the term “pop-action” is derived.

Whether the relief valve opens a slight amount or pops wide open, it will start to close if the pressure in the container diminishes. After the pressure has decreased sufficiently, the relief valve spring will force the seat disc against the seat tightly enough to prevent any further escape of product. The pressure at which the valve closes tightly is referred to as the “re-seal” or “blow-down” pressure. Generally, the re-seal pressure will be lower than the start-to-discharge pressure.

---

### Requirements for Pressure Relief Valves

Every container used for storing or hauling LP-Gas must be protected by a pressure relief valve. These valves are designed to protect the container against the development of hazardous conditions which might be created by any of the following:

- Hydrostatic pressures due to over-filling, or trapping liquid between two points.
- High pressures resulting from exposure of the container to excessive external heat.
- High pressures due to the use of incorrect fuel.
- High pressures due to improper purging of the container.

Consult NFPA #58 for LP-Gas and/or any applicable DOT, local and state regulations governing the application and use of pressure relief valves.

---

### Selection of MEC Pressure Relief Valves for ASME Containers

The rate of discharge required for a given container is determined by the calculation of the surface area of the container as shown in “Chart A” for LP-Gas.

The set pressure of a pressure relief valve depends upon the design pressure of the container. Refer to NFPA #58 “Liquefied Petroleum Gas Code” for more information.

# MEVS-UVE433, MEVS-UVE443, MEVS-UVE453 SEMI-INTERNAL PRESSURE RELIEF VALVES

**Chart A – Minimum Required Rate of Discharge for LPG Pressure Relief Valves Used on ASME Containers**

From NFPA Code #85 (2008), Table 5.7.2.5

Minimum required rate of discharge in cubic feet per minute of air at 120% the maximum permitted start-to-discharge pressure relief valves to be used on containers other than those constructed in accordance with Interstate Commerce specification.

Surface Area Sq. Ft.	Flow Rate CFM Air	Surface Area Sq. Ft.	Flow Rate CFM Air	Surface Area Sq. Ft.	Flow Rate CFM Air	Surface Area Sq. Ft.	Flow Rate CFM Air	Surface Area Sq. Ft.	Flow Rate CFM Air	Surface Area Sq. Ft.	Flow Rate CFM Air	Surface Area Sq. Ft.	Flow Rate CFM Air
20 or less	626	85	2050	150	3260	230	4630	360	6690	850	13540	1500	21570
25	751	90	2150	155	3350	240	4800	370	6840	900	14190	1550	22160
30	872	95	2240	160	3440	250	4960	380	7000	950	14830	1600	22740
35	990	100	2340	165	3530	260	5130	390	7150	1000	15470	1650	23320
40	1100	105	2440	170	3620	270	5290	400	7300	1050	16100	1700	23900
45	1220	110	2530	175	3700	280	5450	450	8040	1100	16720	1750	24470
50	1330	115	2630	180	3790	290	5610	500	8760	1150	17350	1800	25050
55	1430	120	2720	185	3880	300	5760	550	9470	1200	17960	1850	25620
60	1540	125	2810	190	3960	310	5920	600	10170	1250	18570	1900	26180
65	1640	130	2900	195	4050	320	6080	650	10860	1300	19180	1950	26750
70	1750	135	2990	200	4130	330	6230	700	11550	1350	19780	2000	27310
75	1850	140	3080	210	4300	340	6390	750	12220	1400	20380		
80	1950	145	3170	220	4470	350	6540	800	12880	1450	20980		

**Surface area** = Total outside surface area of container, ft<sup>2</sup>

When the surface area is not stamped on the nameplate or when the marking is not legible, the area can be calculated by one of the following formulas:

1. Cylindrical container with hemispherical heads: Area (ft<sup>2</sup>) = [overall length (ft)] x 3.1416
2. Cylindrical container with non-hemispherical heads: Area (ft<sup>2</sup>) = [overall length (ft) + .3 \* outside dia. (ft)] x outside dia. (ft) x 3.1416
3. Spherical container: Area (ft<sup>2</sup>) = [outside dia. (ft)]<sup>2</sup> x 3.1416

**Flow Rate CFM Air** = required flow capacity in cubic feet per minute of air at standard conditions, 60°F, and atmospheric pressure (4.7 psia)

The flow rate discharge may be interpreted for intermediate values of

surface area. For containers with total outside surface area greater than 2000 ft<sup>2</sup>, the required flow rate can be calculated using the formula. Flow Rate in CFM air = 56.632 A<sup>0.82</sup>, where A = total outside surface area of the container, ft<sup>2</sup>

Valves not marked "Air" have rate marking in CFM of liquefied petroleum gas. These can be converted into ratings in CFM air by multiplying the LPG ratings by the factors listed below. Air flow ratings can be converted to ratings in CFM LPG by dividing the air ratings by the factors listed below.

**Air Conversion Factors**

Container Type	100	125	175	200
Air Conversion Factor	1162	1142	1113	1010

The contents of this publication are for informational purposes only. While every effort has been made to ensure accuracy, these contents are not to be construed as warranties or guarantees, expressed or implied, regarding the products or services described herein or for their use or applicability. Marshall Excelsior Co. reserves the right to modify or improve the designs or specifications of such products at any time without notice. The MEC™ logo is the trademark of Marshall Excelsior Co.

# MEVS-UVE433, MEVS-UVE443, MEVS-UVE453 SEMI-INTERNAL PRESSURE RELIEF VALVES

## Installation

**WARNING:** Failure to follow these instructions or to properly install and maintain this equipment could result in an explosion and/or fire causing property damage and personal injury or death. Marshall Excelsior Company equipment must be installed, operated and maintained in accordance with all federal, state and local codes and Marshall Excelsior Company instructions. The installation in most states must also comply with NFPA standards 58 and 59. Only personnel trained in the proper procedures, codes, standards and regulations of the LP-Gas industry should install, maintain and service this equipment.

Be sure all instructions are read and understood before installation, operation and maintenance. These instructions must be passed along to the end user of the product.

**CAUTION:** Contact or inhalation of liquid propane and its vapors can cause serious injury or death! LP-gas must be released outdoors in air currents that will insure dispersion to prevent exposure to people and livestock. LP-Gas must be kept far enough from any open flame or other source of ignition to prevent fire or explosion! LP-Gas is heavier than air and will not disperse or evaporate rapidly if released in still air.

Consult NFPA Codes 58 and 59 and/or any applicable regulations governing the application and use of pressure relief valves. Make sure you are thoroughly trained before you attempt any valve installation, inspection or maintenance.

Proper installation is essential to the safe operation of pressure relief valves. Install MEC pressure relief valves using the following steps:

1. Check that the valve is clean and free of foreign material in the valve inlet and outlet.
2. Verify that the relief valve start-to-discharge setting and flow rate is correct for the application.
3. Verify that the pre-applied thread sealant is intact on the NPT threads
4. Inspect the relief valve inlet and valve seat to ensure no thread sealant or foreign material is present.
5. Install relief valve into container port or manifold using appropriate wrench until leak tight joint is achieved.
6. Check for damage and proper operation after valve installation.
7. After the container is charged with product, check joints for leakage using "Marshall Excelsior" leak detector.
8. After installation is complete, replace protective cover cap onto relief valve.

To properly protect any container, the total system flow must be sufficient to relieve pressure at the pressure setting of the relief valve in accordance with all applicable codes.

## Inspection

A pressure relief valve discharges when some extraordinary circumstance causes an over-pressure condition in the container. If a pressure relief valve is known to have discharged, the relief valve, as well as the entire system, should be immediately and thoroughly inspected to determine the reason for the discharge. In the case of discharge due to fire, the valve should be removed from service and replaced.

Relief valves should be inspected each time the container is filled but no less than once a year. If there is any doubt about the condition of the valve, it must be replaced.

**WARNING:** Eye protection must be worn when performing inspection on relief valves under pressure. Never look directly into a relief valve under pressure or place any part of your body where the relief valve discharge could impact it. In some cases a flashlight and small mirror are suggested to assist when making visual inspections.

In the case of a pressure relief valve that has opened due to a pressure beyond its start-to-discharge setting, the chances of foreign material lodging between the seat and the disc is low, however the possibility is always present. If the relief valve continues to leak at pressure below its start-to-discharge setting it must be replaced.

If there is any doubt about the condition of the relief valve, or if the relief valve has not been protected by a cap for some time, it should be replaced before refilling the container.

## Inspection Checklist:

1. **Cap:**  
Check that the protective cover cap is in place over the valve outlet and has a snug fit.  
The cover cap helps protect the relief valve against possible malfunction caused by rain, sleet, snow, ice, sand, dirt, pebbles, insects, other debris and contamination.  
**REPLACE DAMAGED OR MISSING CAPS AT ONCE AND KEEP A CAP IN PLACE AT ALL TIMES**
2. **Relief Valve Spring:**  
Exposure to high concentrations of water, salt, industrial pollutants, chemicals and contaminants could cause metal parts to fail including the relief valve spring.  
**IF DURING VISUAL INSPECTION THERE ARE ANY INDICATIONS OF DAMAGE OR CORROSION, REPLACE THE VALVE**
3. **Physical Damage:**  
Ice accumulations and improper installation could cause mechanical damage.  
**IF THERE ARE ANY INDICATIONS OF DAMAGE, REPLACE THE VALVE**
4. **Tampering or Readjustment:**  
Pressure relief valves are factory-set to discharge at specified pressures.  
**IF THERE ARE ANY INDICATIONS OF TAMPERING OR READJUSTING, REPLACE THE VALVE**

# MEVS-UVE433, MEVS-UVE443, MEVS-UVE453 SEMI-INTERNAL PRESSURE RELIEF VALVES

## Inspection Checklist, Cont...

### 5. Seat Leakage:

Check for leaks in the seating area using Marshall Excelsior leak detecting solution

### 6. Corrosion: REPLACE THE VALVE IF THERE ARE ANY SIGNS OF CORROSION OR CONTAMINATION

### 7. Moisture, Foreign Particles or Contaminants in the Valve:

Foreign material such as paint, tar or ice in relief valve parts can impair the proper functioning of the valves. Grease placed in the valve body may harden over time or collect contaminants, thereby impairing the proper operation of the relief valve.

**DO NOT PLACE GREASE IN THE VALVE BODY;  
REPLACE THE VALVE IF THERE ARE ANY  
INDICATIONS OF MOISTURE OR FOREIGN MATTER IN  
THE VALVE**

### 8. Corrosion or leakage at container connection:

Check container to valve connection using Marshall Excelsior leak detector solution.

**REPLACE THE VALVE IF THERE IS ANY INDICATION  
OF CORROSION OR LEAKAGE AT THE CONNECTION  
BETWEEN THE VALVE AND CONTAINER.**

**CAUTION:** Never plug the outlet of a pressure relief valve. Any device used to stop the flow of a properly operating pressure relief valve that is venting an over pressurized container can cause severe consequences.

## Replacement of Pressure Relief Valves

**WARNING:** Under normal conditions, the useful safe service life of a pressure relief valve is 10 years from the original date of manufacture. However, the safe useful life of the valve may be shortened and replacement required in less than 10 years depending on the environment in which the valve lives. Inspection and maintenance of pressure relief valves is very important. Failure to properly inspect and maintain pressure relief valves could result in personal injuries or property damage.

The safe useful life of pressure relief valves can vary greatly depending on the environment in which they live.

Relief valves are required to function under **widely varying** conditions. Corrosion, aging of resilient seat disc and friction all proceed at different rates depending on the nature of the specific environment and application. Gas impurities, product misuse and improper installations can shorten the safe life of a relief valve. The LP-Gas dealer must observe and determine the safe useful life of relief valves in his systems.

### For additional information read:

1. NFPA #58, "Storage and Handling of Liquid Petroleum Gases"
2. NFPA #59, "LP-Gases and Utility Gas Plants"

Relief valves in service beyond their service life can exhibit the following degradation in function:

- They may leak at pressures below the set pressure.
- They may open and fail to properly reseal.
- They may open at higher than set pressure.

These failures to function properly are due primarily to four "environmental" conditions:

1. Corrosion of metal parts (particularly springs) which result in the component parts failing to perform.
2. Deterioration of synthetic rubbers eat disc material.
3. Clogging or "cementing" of the movable relief valve components so that their movement is restricted.
4. Debris on the valve seat after the relief valve opens, effectively preventing the valve from resealing.

Corrosion is caused by water, corrosive atmospheres of salt and high industrial pollutants, chemicals, and contaminants. High concentrations can attack the metal parts vigorously. NO suitable metals are totally resistant to such corrosion.

Synthetic rubber and seat disc materials can also be attacked by impurities in the gas and corrosive atmospheres, particularly those with Sulphur dioxide. There are no suitable rubber materials which resist all contaminants.

"Cementing" of relief valve parts can be caused by normal industrial atmospheres containing particles of dirt, iron oxide, metal chips, etc. combined with water, oil, or grease. Ice collecting in recessed valves could cause failure to open. Paint and tar in relief valves also cause failure to function properly.

## Relief valve safety information

### Repair and Testing

MEC Pressure Relief Valves are tested and listed by Underwriters Laboratories, Inc., in accordance with UL 132 and NFPA Code #58. Construction and performance of MEC Pressure Relief Valves are consistently checked at the factory by UL audits. Therefore, testing of MEC Pressure Relief Valves in the field is not necessary.

**WARNING:** Never attempt to repair or change the setting of MEC Pressure Relief Valves. Any changes in settings or repairs in the field will void the MEC warranty and product listings, and may create a serious hazard.

While the functioning of a pressure relief valve appears to be relatively simple, the assembly and test procedure used to manufacture these MEC products is rather complex. Highly specialized test fixtures and specially trained personnel are necessary to attain proper relief valve settings. These fixtures and personnel are available only at the factory.

**Any pressure relief valves which shows evidence of leakage, other improper operation or is suspect as to its performance must be replaced immediately using approved procedures.**

MEVS-UVE433, MEVS-UVE443, MEVS-UVE453  
SEMI-INTERNAL PRESSURE RELIEF VALVES

---



**Marshall Excelsior Company**  
1506 George Brown Drive Marshall, MI 49068  
Phone (269) 789-6700 Fax (269) 781-8340  
[www.marshallexcelsior.com](http://www.marshallexcelsior.com)