

ME601-10SRK



WARNING: These products contain a chemical known to the state of California to cause cancer and birth defects or reproductive harm

Contents:

(1) Bonded Valve, (1) Valve Spring, (1) Valve Retainer, (1) Gasket, (1) Acme Gasket, (1) Packet Loctite

Instructions for Seal Replacement:

1. Remove acme gasket, valve retainer, bonded valve, valve spring and gasket and discard.
2. Install valve spring on bonded valve and install into body and over plunger.
3. Install gasket on shoulder of body.
4. Apply loctite to exterior threads on valve retainer and tighten into body.
5. Install acme gasket in groove in body.

