



**WARNING:** These products contain a chemical known to the state of California to cause cancer and birth defects or reproductive harm



Figure 1

The ME980-907 Eutectic Elbow fitting (Figure 1) is designed for installation in systems such as direct-fired vaporizers.



Figure 2

The eutectic fittings should be installed in locations that are likely to be impinged directly by flame, such as the vent discharge of the supply regulator and near the electronic control inside the cabinet (Figure 2).



Figure 3

Where possible, eutectic fittings should be installed in locations that offer suitable protection from mechanical damage (Figure 3). For maximum reliability, connections that are exposed to elevated operating temperatures, such as inside vaporizer cabinets, should be made with metallic tubing.

### Marshall Excelsior Company

1506 George Brown Drive Marshall, MI 49068  
Phone (269) 789-6700 Fax (269) 781-8340  
[www.marshallexcelsior.com](http://www.marshallexcelsior.com)

The contents of this publication are for informational purposes only. While every effort has been made to ensure accuracy, these contents are not to be construed as warranties or guarantees, expressed or implied, regarding the products or services described herein or for their use or applicability. Marshall Excelsior Co. reserves the right to modify or improve the designs or specifications of such products at any time without notice. The MEC™ logo is the trademark of Marshall Excelsior Co.